

The manual of the device SEL-08

1. Place the device on the conference table or desk. The recommended distance from the person whose recording device will be jammed 0.5 to 4 meters.

Please remember that on the effectiveness of the work of the device has influence: the way of the location device and the forces of the intensity of the voice of the protected person - the voice weaker and quiet = the better effectiveness.



1. The switching on-of the device - (the main on-switch).



a) Press the switch. The switch will turn RED - the device will be ready for operation.

b) the device is powered on and off by pressing the green button on the remote control
turning on the device signals double flashing of the red diode in the signal line,
turning off the power supply - the red LED flash once

The charging a battery:

After connecting the AC adapter to the SEL-08 device, the charging process begins. The following LEDs will light up in the line:

- LED red flashing - meaning completely discharged accumulator, immediately to connect the AC adapter
- LED red in the switch – the accumulator charge
- LED blue flashing – the final phase of the charging

The accumulator fully charged when LED blue flashing

The time of the charging battery about 3 hours

Conditions of the safety:

- a) do not open the device, breaking the seals involves immediate loss of the warranty.
- b) during the work next door to device should not be found animals.

Features:

- remote radio on - switching off using the remote control
- quiet operation - no audible and bothersome sound
- battery charge indicator and status indicator (continuous blue led flashing when on/off means the battery is above 75%, below 75% blue led will stop flashing)
- simple exploitation.

Specifications:

- maximum range: depending on the eavesdropping one ought to accept the area 05 - 4 meters
 - directivity of the work of the device SEL-08 in the ground plane 85 °
in the vertical plane 85 °
- control by means of a wireless remote control - switching on and off, working range about 20 meters.
- wireless remote control: operating frequency 433.92 MHz in the ISM band
- power supplies: the built-in internal accumulator Li-ion / the power supply 5V/110-230V
- maximum continuous operating time 4-5 hours, break time 30 minutes.
- work time from the built-in accumulator about 4-5 hour
- time of the battery charging 3 hours
- weight: 550 grams
- the range of the work in the temperature from 0 ° to + 40 ° C (32-104 Fahrenheit)
- size: 200 x 120 x 40 mm

DUE TO TECHNOLOGICAL LIMITATIONS, SOME RECORDER DEVICES CAN NOT BE SUPPRESSED, WHICH IS NOT A MALFUNCTION OF “SEL-08”.

WARRANTY OBLIGATIONS

Warranty period - 12 months from the date of sale.

In case of failure of the device during the warranty period, the owner has the right to warranty repairs. In case of violation of seals, mechanical damage to the case or controls, the right to warranty is lost, and repairs are carried out at the expense of the owner.